Based on release	Yocto: Poky 2.5, BSP: NXP Sumo BSP L4.14.98-2.0.0_ga, Linux: Freescale imx_4.14.98-2.0.0_ga
Nature of release	Variscite Yocto Sumo i.MX8QM Release V1.6
Date	12/8/2019
Supported platform	VAR-SOM-MX8/SPEAR-MX8
SOM revision	v1.1 and higher
Carrier board revision	v1.1 and higher
Variscite BSP git	https://github.com/varigit/meta-variscite-imx
Variscite BSP branch	sumo-imx-4.14.98-var01
Variscite BSP commit ID	bf663250b6851b833a4cb32bd39b59bf93f7035
Kernel git	https://github.com/varigit/linux-imx
Kernel branch	imx_4.14.98_2.0.0_ga_var01
Kernel commit ID	680f822e1370c34160f0126b5710b14d1647694f
U-Boot git	https://github.com/varigit/uboot-imx
U-Boot branch	imx_v2018.03_4.14.98_2.0.0_ga_var01
U-Boot commit ID	9da725ccf4f80881a989e084e1200d7b237dd63e
File System build system	Yocto Sumo
Recovery SD card link	var-som-mx8-recovery-sd.v16.img.gz
Change list	Description
Release 1.6	
Upgraded SCFW to version 1.2.8	Required to support latest CPU and PMIC revisions
Release 1.5	
Added Android support for SPEAR-MX8	
Fixed capacitive touch interrupt for VAR-SOM-MX8	Fixes capacitive touch on Symphony board v1.2, backwards compatible with older Symphony revisions
Release 1.4	
Added Yocto support for SPEAR-MX8	
Release 1.3	
Added Android support for VAR-SOM-MX8	
Release 1.2	
Added HDMI and DP support for VAR-SOM-MX8	HDMI and DP displays are now supported via Variscite extension modules
Fixed DRAM instability problem	Updated to latest NXP ATF release that fixes Cortex A72 cache configuration
Disabled U-Boot splash on LVDS display	Fixes U-Boot hang on reboot when HDMI or DP displays are connected
Fixed occasional WIFI driver crashes on reboot/poweroff	Do not stop Variscite WiFi service or reboot/poweroff as this causes occasional WiFi driver crashes
Release 1.1	
nitial Yocto release for VAR-SOM-MX8	
Known issues	
SATA is disabled on SPEAR-MX8	i.MX8QM SATA support in Linux is currently not stable, disabled in DTS
USB Type-A ports are not supported in U-Boot on SPEAR-MX8	